

Manual Configuration of VoIP Phone

Our control panel provides auto-provision facilities for over 70 models of phones. Where possible we would encourage you to make use of this. However, should you have a model which isn't supported, then the following instructions will guide you through the typical settings you'll need.

IP Scanning

To access the settings page for most phones, you need to connect the phone to your network and power it up. A dynamic IP address should be assigned to your device. To help discover what this IP address is, there are scanners which may help:

- For Mac - [LanScan](#)
- For Windows - [Advanced IP Scanner](#)

Alternatively, you can seek confirmation from the phone itself. However, as each phone is different it's difficult to provide specific instructions, hence the scanner is often the quickest and simplest option.

Browser Entry

To your browser of choice and simply enter the IP address assigned to your phone (eg 192.168.0.23) without www or http:// appended.

Key Settings

Host	Check your panel for confirmation (eg account.intervoip.co.uk)
Port	5060
Username	eg user_123abc
Password	*****
DNS SRV	Enabled